

USING THE TCL #C1 DOUBLE CROSSOVER AS AN ILLUSTRATION FOR WIRING THE PPB

This is a sample for a step by step illustration of how to wire the PCBs on the PRE-DRILLED PANEL BOARD. I am going to use the #C1 DOUBLE CROSSOVER from the Track Configuration Library for this example. The same sequence will apply to all the files with just a change in the PCB arrangement. Make sure that you do all of the checks when indicated to do so. If you have any questions, please e-mail or call Custom Signals. The C1 Track Layout is illustrated below.

